


myhappyhelpers

play. create. discover.

Assembly instruction


These assembly instructions must be read in conjunction with the Addendum to the safety instructions attached. This provides guidance on safety and usage of the product.






A	B	C	D	E
2PCS	1PC	2PCS	3PCS	1PC


1#	2#	3#	4#	5#
Ø15	Ø6*38mm	Ø8*30mm	4mm	
18+2PCS	16+2PCS	6+1PCS	1PC	2PCS




1




1 #	D	E
		
Ø15		
3PCS	1PC	1PC




2




1 #	D	B
		
Ø15		
3PCS	1PC	1PC


3




1#	D	C
		
Ø15		
3PCS	1PC	1PC


4






1#

Ø15
9PCS







5



2#	3#
	
$\phi 6 \times 38 \text{mm}$	$\phi 8 \times 30 \text{mm}$
16PCS	6PCS


A

2PCS



6#	
	
	
25mm	15mm
2PCS	

WALL

WALL



SECURE YOUR FURNITURE

If furniture tips over it can cause serious injury. The best way to help prevent furniture tip-over accidents is to secure furniture to the wall. My Happy Helpers urges customers to inspect their shelves and furniture to ensure that they are securely anchored to the wall using the restraints provided in the packaging. Should you need a replacement restraint kit to secure the furniture in your home, you can purchase at local hardware store.

Tips to prevent furniture tip-over accidents

Furniture must be securely attached to the wall.

Use the tip-over restraint provided with the product and the right hardware for your wall type.

Consult our wall anchoring guide for help. Never put heavy objects on top of shelves or any furniture.

Place heavy objects on the lowest shelves.

Never let children climb or hang on shelves.

Information on wall anchoring

The hardware used to secure your furniture to the wall depends on your wall material.

If your wall material is not listed or if you have any questions, consult with your local hardware retailer.

Wall material: Drywall or plaster with available wood stud

Anchoring device: Screw inserted directly into stud.

Wall material: Drywall without available wood stud

Anchoring device: Plug with screw.

Wall material: Masonry

Anchoring device: Solid Wall: Plug and screw / Hollow wall: Toggle-style

INSTRUCTIONS FOR USE - IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Manufacturer: My Happy Helpers

Address: 1591, 1007 N Orange Wilmington, DE, New Castle US 19801

Telephone: 1 (800) 458-3750

www.myhappyhelpers.com

Product: Aspire Open Bookshelf

Made in PRC

WARNINGS

- This item can become unstable and may topple if climbed upon by children. This may cause serious harm or death to a child.
- The degree of instability depends on many variables and the purchaser needs to be aware of potential instability problems and seek to minimize them. Furniture/Shelving items can tip under certain circumstances especially when placed on carpet, uneven or sloping flooring, or when subject to extreme use. Care must be taken especially where small children can access the furniture item.
- Do not place this product near a window as it can be used as a step by the child and cause the child to fall out the window.
- Strangulation hazard – do not place this product close to components which could present a danger of suffocation such as for example: blind/curtain cords.
- Do not use if any of the components are broken, torn or missing.
- To avoid danger of suffocation, plastic bags and other plastic elements should be removed immediately and kept out of reach of babies and children. Do not use plastic bags or other plastic elements in cribs, beds, carriages or playpens. Plastic bags are not a toy.
- The screws and parts used in assembly are small parts. These must not be accessible to children under 3 years of age.

Product Guidelines

- The product must be assembled by an adult in accordance with the assembly instructions attached.
- Do not over-tighten hardware as this may cause the wood to crack. Do NOT use an electric drill to assemble.
- The product is for domestic and indoor use only.
- The product must only be used on flat surfaces.
- Do not use the product if any part is broken or missing.
- Only use spare parts approved by My Happy Helpers.

Anchoring this product

- Attachment of this furniture item to an appropriate structural component of the building using suitable means is strongly recommended.
- To avoid this product from toppling over onto playful children this furniture item must be anchored to the wall in accordance with the attachment and instructions provided.

- Please perform regular checks of the anchor to ensure that it remains tight.

Ongoing maintenance of the Product

- Over time and at regular intervals an adult should carry out checks of the product. This at a minimum should include checking the screws for tightness and tighten when required. Care should always be taken to ensure no screws are ever lose because a child could trap parts of their body or clothing (eg strings, necklaces, ribbons for babies' dummies, etc) which could pose a risk of strangulation.

Disposal Instructions

- When the owner decides to disassemble or dispose of this product please ensure that no unreasonable hazards exist at the time this product is discarded.
- When the product is disassembled the screws and parts are small parts. These must not be accessible to children under 3 years of age.