INSTRUCTIONS FOR USE - IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Manufacturer: My Happy Helpers

www.myhappyhelpers.com Product: Dine and Grow Chair – All types & Colours Age Grading: 3+ years

Made in PRC



- Furniture items can tip under certain circumstances especially when placed on carpet, uneven or sloping flooring, or when subject to extreme use. Care must be taken especially where small children can access the furniture item.
- Do not place this product near a window as it can be used as a step by the child and cause the child to fall out the window.
- Do not place this product close to components which could present a danger of suffocation such as for example: blind/curtain cords.
- Keep this product inaccessible to children when not in use. Adult supervision required at all times.
- Do not use if any of the components are broken, torn or missing.
- This product must not be used by adults.
- To avoid danger of suffocation, plastic bags and other plastic elements should be removed immediately and kept out of reach of babies and children. Do not use plastic bags or other plastic elements in cribs, beds, carriages or playpens. Plastic bags are not a toy.
- The screws and parts used in assembly are small parts. These must not be accessible to children under 3 years of age.

Product Guidelines

- The product must be assembled by an adult in accordance with the assembly instructions attached.
- Do not over-tighten hardware as this may cause the wood to crack. Do NOT use an electric drill to assemble.
- The product is intended for use by children from ages 3 years to 6 years.
- The product is for domestic and indoor use only.
- The product must only be used on flat surfaces.
- Do not use the product if any part is broken or missing.

• Only use spare parts approved by My Happy Helpers.

Operating Instructions

- The product must only be used under adult supervision at all times.
- This product is designed for use by 1 child at a time.
- The maximum weight to be used on this product is 50kgs.
- Keep this product out of reach of children when not in use.
- Instruct the children not to attach items to the equipment not specifically designed for use with the equipment.

Ongoing maintenance of the Product

• Over time and at regular intervals an adult should carry out checks of the product. This at a minimum should include checking the screws for tightness and tighten when required. Care should always be taken to ensure no screws are ever loose because a child could trap parts of their body or clothing (eg strings, necklaces, ribbons for babies' dummies, etc) which could pose a risk of strangulation.